



Do not get the lamp wet. Do not charge the lamp when it is raining unless you put it inside a plastic bag to keep it dry.

The battery in the lamp can be fully discharged up to 1500 times.

If you fully discharge the battery every night it will last 4 years.

If you half discharge the battery every night it will last 8 years.

When the battery is fully charged it can run for 8 hours on half brightness (first button click) and 5 hours on full brightness (second button click).

When the battery is fully charged the lamp will last 8 years if you only use it each night for less than 2.5 hours on full brightness or 4 hours on half brightness.

A flat battery will be fully charged after 6 hours in bright sunlight.

A half flat battery will be fully charged after 3 hours in bright sunlight.

It does not damage the battery if you leave the battery in the sun after it is fully charged.

These instructions can be found on the internet at harvest.com/manuals.